

TIS 1310 LED LUX Meter

Short User Guide



1. **Power On** by pressing the yellow power button in the top left corner. The TIS 1310 will default to normal Lux / Auto setting.
2. **Zero / Calibrate** the TIS 1310 **with the lens cover on** by pressing the hold/zero button for >1 second. "Adj" will be displayed followed by a long beep. Zero will be displayed on the screen. The instrument is now ready for use. Please place the TIS 1310 directly in line with the light source and at right angles to it.
3. **Remove Lens Cover** and the Lux reading will be displayed on the screen
4. **To switch between LED & Lux mode** press the Max/Min/LS button >1 second. The Light source can now be selected. Please refer to the rear of the lens cap for a guide or Page 22 of the user manual for detailed information.
5. **The Rel/Peak** button allows you to toggle between relative & peak modes if you need to take readings in more than one location. A short press selects Rel. A long press selects Peak. Another long press will return to normal mode.
6. **If there are multiple light sources** you can adjust the distance by pressing Lx/Fc/CD button for >1 second. Adjust the distance of the meter from the light source using the up / down arrow buttons.
7. **To mute the beep** short press the power button at any time. To activate the beep short press the power button again.
8. **To manually select the range** short press the RAN button and repeatedly press RAN until the desired Range is selected. Please refer to Page 17 of the user manual for further information. To return to Auto mode long press RAN button for >1 second
9. **To switch the power off** long press the power button. The instrument will auto power off after 10 minutes of inactivity. Please remove battery if not in use for long periods of time.

For a comprehensive and detailed user guide, please refer to the manual supplied with your TIS 1310