

## Product information

# 95 26 165 SB

## Cable Shears

With opening spring

IEC 60900 DIN EN 60900

- Clean and smooth cut without crushing and deformation
- Easy cutting with one-hand operation
- Adjustable bolted joint, self-retaining screw
- Cuts multi-core stranded copper and aluminium cables up to Ø 15 mm (50 mm<sup>2</sup>)
- Not suitable for steel wire and hard drawn copper conductors
- Precision-ground, hardened blades
- With guard



⚡ 1000 V 

### General

Article No.	95 26 165 SB
EAN	4003773070139
Shears	chrome-plated
Handles	insulated with multi-component grips, VDE-tested
Weight	275 g
Dimensions	165 x 84 x 21 mm
Standard	DIN EN 60900 IEC 60900
REACH compliant	does not contain SVHC
RoHS compliant	not applicable

### Technical details

Cutting capacity copper cable, multiple-stranded	50 mm <sup>2</sup>
Cutting capacity copper cable, multiple-stranded	Ø 15 mm
AWG	1 / 0
VDE tested	yes

*technical change and errors excepted*



Cut performed with a Cable Shear: easy, clean cut without any deformation of the cable



95 26 165: Catch locks shears with internal opening spring

