

Screwdriver set SoftFinish® electric Slotted, Pozidriv 6-pcs (25477)



Wiha Werkzeuge GmbH
Obertalstraße 3-7
78136 Schonach
E-Mail: info.de@wiha.com
Tel.: +49 (0)7722 959-0

Order no.: 25477

Article number: 25477

EAN: 4010995254773

Customs tariff number: 82054000

Increases your efficiency: Unique Wiha handle-length concept for optimum balance of torque and control.

Protects your health: With the patented SoftFinish® handle design, ensuring work is kind to hands and muscles. Recommended by doctors and therapists at German Campaign for Healthier Backs.

Offers you full protection: Each tool individually tested at 10,000 V AC and approved for 1,000 V AC.

Product dimensions: 353 x 44 x 237 mm (LxWxD)

Application: For work in the area of live parts up to 1,000 V AC.

Handle: Ergonomic Wiha SoftFinish® multi-component handle with roll-off protection.

Blade: High quality chrome-vanadium-molybdenum steel, through hardened, black-finish.

Blade: Insulation moulded directly onto blade.

Ergonomic working – Recommended by doctors and therapists of the German Campaign for Healthier Backs

Wiha handle size concept - powerful and sensitive fastening

Safe operation up to 1,000 V AC

Fastening screws by hand causes considerable strain on wrists and muscles in the long term. The highly ergonomically shaped SoftFinish® screwdriver provides a remedy, ensuring optimal transmission of hand force. The different handle heights are always matched to the fastening. The long, slender handle heights can be used to fasten small screws quickly and firmly. There are also large-volume handle heights to fasten large screws which can be used to apply greater torques. The roll-off protection and screw symbol printed on the handle end ensure users work efficiently. Thanks to its optimum grip, the SoftFinish® screwdriver is particularly suitable for applications in dry environments. The position of the soft and hard zones on the handle also supports the perfect grip for quick and powerful turning. These insulated screwdrivers undergo routine individual piece testing as per the international IEC 60900 standard, thus providing users with a tool to work safely on live parts up to 1,000 V AC.

Manufactured acc. to IEC 60900.

Content:

- 1x Screwdriver SoftFinish® electric Slotted 2.5 mm x 75 mm (00820)
- 1x Screwdriver SoftFinish® electric Slotted 3.5 mm x 100 mm (00822)
- 1x Screwdriver SoftFinish® electric Slotted 4.5 mm x 125 mm (00824)

- 1x Screwdriver SoftFinish® electric Slotted 5.5 mm x 125 mm (00826)
- 1x Screwdriver SoftFinish® electric Pozidriv PZ1 x 80 mm (00878)
- 1x Screwdriver SoftFinish® electric Pozidriv PZ2 x 100 mm (00879)

Customs tariff number	82054000
-----------------------	----------

Self service - packing	No
------------------------	----

Tool for electrics	Yes
--------------------	-----

Country of origin (ISO 3166-1 Alpha 3)	DEU
--	-----
