

**Torque screwdriver set TorqueVario®-S electric
0,8-5,0 Nm mixed, variably adjustable torque limit,
19 pcs. incl. folding bag (36791)**



Wiha Werkzeuge GmbH
Obertalstraße 3-7
78136 Schonach
E-Mail: info.de@wiha.com
Tel.: +49 (0)7722 959-0



Order no.: 36791

Article number: 36791

EAN: 4010995367916

Customs tariff number: 82079030

Meets your requirements: Variably adjustable torque covers a wide range of applications.

Simplifies your work: All tools securely arranged in a robust, orderly bag.

Increases your efficiency: The correct torque protects material from damage and means no follow-up work.

Protects your health: With the patented SoftFinish® handle design, ensuring work is kind to hands and muscles. Recommended by doctors and therapists at German Campaign for Healthier Backs.

Lowers your costs: The correct torque protects you from warranty claims.

Offers you full protection: Each tool individually tested at 10,000 V AC and approved for 1,000 V AC.

Increases your safety: Wiha slimBits ensure good, protected access to deep-set screws.

Product dimensions: 246 x 45 x 225 mm (LxWxD)

Application: For controlled fastening on live parts up to 1 000 V AC.

Extra: Incl. works inspection protocol.

Standards: Manufactured acc. to IEC 60900.

Variably adjustable torque from 0.8 - 5.0 Nm

Acoustic and physically perceptible triggering signal protects against damage to materials and rework
slimBits allow access to low-lying screws thanks to inserted insulation

Safe operation up to 1,000 V AC

Expandable and compatible with EVF products

With handle, 15 slimBits, adapter and setting tool in a practical and robust folding bag

The fully certified TorqueVario®-S VDE torque system offers fully controlled screw tightening coupled with safety for electronic applications. The tool set contains an ergonomically shaped torque screwdriver handle with integrated numerical scale, 15 slimBits, a bit holder, and the adjusting tool. All components are arranged practically and clearly in a high-grade, hard-wearing bag, incl. the manufacturer's inspection process report. The VDE torque screwdriver covers a wide variety of applications with a variably adjustable torque range between 0.8 and 5.0 Nm. A clearly audible, physically perceptible signal emitted when the torque is produced guarantees process-safe torque mechanics, protecting against damage to materials and eliminating the need for retouching. With a release accuracy of +/-6%, the torque tool complies with the requirements of DIN EN ISO 6789. The insulated ClicFix bit holder guarantees a secure

hold for 75 mm long slimBits thanks to mechanical blade locking. Both the torque screwdriver and the slimBits undergo routine testing as per the international IEC 60900 standard, allowing users to work safely on live parts up to 1,000 V AC.

DIN EN ISO 6789.

Content:

- 1x Torque screwdriver TorqueVario®-S electric variably adjustable torque limit 0.8 - 5 (26626)
- 1x Setting tool for torque screwdriver with long handle 90 mm (26864)
- 1x Adapter TorqueVario-S electric for slimBits 6.0 mm (35870)
- 1x slimBit electric bit Slotted 2.5 mm x 75 mm (34578)
- 1x slimBit electric bit Slotted 3.5 mm x 75 mm (41159)
- 1x slimBit electric bit Slotted 5.5 mm x 75 mm (34581)
- 1x slimBit electric bit Slotted 6.5 mm x 75 mm (34582)
- 1x slimBit electric bit Phillips PH1 x 75 mm (34583)
- 1x slimBit electric bit Phillips PH2 x 75 mm (34584)
- 1x slimBit electric bit Pozidriv PZ1 x 75 mm (34585)
- 1x slimBit electric bit Pozidriv PZ2 x 75 mm (34586)
- 1x slimBit electric bit PlusMinus/Pozidriv SL/PZ1 x 75 mm (34589)
- 1x slimBit electric bit PlusMinus/Pozidriv SL/PZ2 x 75 mm (34590)
- 1x slimBit electric bit TORX® T9 x 75 mm (41160)
- 1x slimBit electric bit TORX® T10 x 75 mm (35507)
- 1x slimBit electric bit TORX® T15 x 75 mm (35508)
- 1x slimBit electric bit TORX® T20 x 75 mm (35509)
- 1x slimBit electric bit TORX® T25 x 75 mm (36071)
- 1x Folding bag

Customs tariff number	82079030
-----------------------	----------

Self service - packing	No
------------------------	----

Tool for electrics	Yes
--------------------	-----

Country of origin (ISO 3166-1 Alpha 3)	DEU
--	-----
