

**Screwdriver with bit magazine LiftUp electric  
Phillips, PlusMinus/Pozidriv, slotted with 6 slimBits  
in SB-cardboard packaging (38613)**



Wiha Werkzeuge GmbH  
Obertalstraße 3-7  
78136 Schonach  
E-Mail: [info.de@wiha.com](mailto:info.de@wiha.com)  
Tel.: +49 (0)7722 959-0

**Order no.:** 38613

**Article number:** 38613

**EAN:** 4010995386139

**Customs tariff number:** 82054000

**Increases your efficiency:** Wiha LiftUp electric saves 75% volume and 50% less weight for 100 % efficiency.

**Protects your health:** No risk of injury, all blades stowed safely inside the handle.

**Offers you full protection:** Each tool individually tested at 10,000 V AC and approved for 1,000 V AC.

**Increases your safety:** Wiha slimBits ensure good, protected access to deep-set screws.

**Product dimensions:** 342 x 41 x 130 mm (LxWxD)

**Application:** Suitable for controlled fastening for live parts up to 1,000 V AC, especially for portable use.

Clearly arranged and easy to remove

Saves 75% of space

slimBits allow access to low-lying screws thanks to inserted insulation

Expandable and compatible with EVF products

Safe operation up to 1,000 V AC

The screwdriver with the bit magazine LiftUp electric is the ideal companion for every electrician out on a job. The bit depot hidden in the handle provides space for 6 standard slimBits and extends out of the magazine at the press of a button. This makes it easy to remove the 75 mm slimBits. The insulated metal ClicFix bit holder grips all slimBits securely and reliably locks them into place. This technology transforms the bit magazine into an all-purpose screwdriver. The magazine bit holder also ensures maximum safety. Both the magazine bit holder and the slimBits that it contains are certified as per international IEC 60900 standard. The slender, 75 mm slimBits ensure perfect access to low-lying screws or spring clamps thanks to protective insulation fully integrated into bits in the front section. The twistable cap brings a further advantage, ensuring convenient handling. The 75 mm slimBits are compatible with all products in the Wiha ElectricVario family.

Manufactured acc. to IEC 60900.

Content:

- 1x slimBit electric bit Slotted 3.0 mm x 75 mm (34579)
  - 1x slimBit electric bit Slotted 4.0 mm x 75 mm (34580)
  - 1x slimBit electric bit Slotted 5.5 mm x 75 mm (34581)
  - 1x slimBit electric bit Phillips PH1 x 75 mm (34583)
  - 1x slimBit electric bit Phillips PH2 x 75 mm (34584)
  - 1x slimBit electric bit PlusMinus/Pozidriv SL/PZ2 x 75 mm (34590)
-

|                       |          |
|-----------------------|----------|
| Customs tariff number | 82054000 |
|-----------------------|----------|

---

|                        |     |
|------------------------|-----|
| Self service - packing | Yes |
|------------------------|-----|

---

|                    |     |
|--------------------|-----|
| Tool for electrics | Yes |
|--------------------|-----|

---

|                                           |     |
|-------------------------------------------|-----|
| Country of origin (ISO<br>3166-1 Alpha 3) | POL |
|-------------------------------------------|-----|