

Screwdriver with bit holder set slimVario® electric Stubby 4 pieces with slimBits (41230)



Wiha Werkzeuge GmbH
Obertalstraße 3-7
78136 Schonach
E-Mail: info.de@wiha.com
Tel.: +49 (0)7722 959-0



Order no.: 41230

Article number: 41230

EAN: 4010995412302

Customs tariff number: 82054000

Simplifies your work: Compact handle – maximum power.

Increases your efficiency: Fully compatible with the Wiha slimBit system.

Offers you full protection: Each tool individually tested at 10,000 V AC and approved for 1,000 V AC.

Increases your safety: Wiha slimBits ensure good, protected access to deep-set screws.

Increases your safety: Protected work in constricted spaces.

Product dimensions: 198 x 43 x 130 mm (LxWxD)

Application: For work in the area of live parts up to 1,000 V AC. Ideal for use in a confined working environment.

Perfect for confined spaces

slimBits allow access to low-lying screws thanks to inserted insulation

Safe operation up to 1,000 V AC

Expandable and compatible with EVF products

With handle and 4 slimBits

Tradesmen require short, handy screwdrivers for electrical work in cramped work environments. This often means the handle is shortened or electricians work with non-insulated screwdrivers, thus compromising their own safety. Wiha offers the optimal problem solution for such cases in its insulated Stubby short screwdriver. Thanks to the overall length of just 105 mm, it is perfect for working in confined spaces. The short screwdriver is also fully compatible with slimBits, meaning the whole range of screw profiles are covered. Protective insulation has been integrated into the blade with the Wiha slimTECHNOLOGY specially developed for electric applications, thus ensuring blades which are up to 33% slimmer. This means low-lying screw and spring elements can also be easily reached. The Stubby handle and slimBits undergo routine individual piece testing as per the international IEC 60900 standard, as a result* providing users with a tool to work safely on live parts up to 1,000 V AC. The 75 mm slimBits are compatible with all products in the Wiha ElectricVario family.

Manufactured acc. to IEC 60900.

Content:

- 1x Screwdriver with bit holder SoftFinish® electric slimVario Stubby 6.0 mm (41229)
- 1x slimBit electric bit Slotted 3.5 mm x 75 mm (41159)

- 1x slimBit electric bit Phillips PH2 x 75 mm (34584)
- 1x slimBit electric bit PlusMinus/Pozidriv SL/PZ2 x 75 mm (34590)

Customs tariff number	82054000
Self service - packing	Yes
Tool for electrics	Yes
Country of origin (ISO 3166-1 Alpha 3)	DEU
