

Fine screwdriver set PicoFinish® slimVario® electric 4-pcs. with slimBits (43167)



Wiha Werkzeuge GmbH
Obertalstraße 3-7
78136 Schonach
E-Mail: info.de@wiha.com
Tel.: +49 (0)7722 959-0

Order no.: 43167

Article number: 43167

EAN: 4010995431679

Customs tariff number: 84661038

Increases your efficiency: Fully compatible with the Wiha slimBit system.

Increases your efficiency: Careful workmanship and controlled power transmission thanks to the slim handle with soft grip.

Increases your efficiency: Particularly suitable for use with slimBit profiles.

Offers you full protection: Each tool individually tested at 10,000 V AC and approved for 1,000 V AC.

Increases your safety: Wiha slimBits ensure good, protected access to deep-set screws.

Product dimensions: 198 x 27 x 130 mm (LxWxD)

Application: Ideal for delicate and high-precision fastening tasks for electrical installations and live parts. Filigree fastening work

Permits quick rotation thanks to the rotating cap

slimBits allow access to low-lying screws thanks to inserted insulation

Safe operation up to 1,000 V AC

Expandable and compatible with EVF products

With handle and 4 slimBits

The challenge in precision screw fastenings is to work meticulously and carefully without damaging the work piece. Thanks to its long, slim handle and quick-turning zone, the Wiha PicoFinish® fine screwdriver is ideal for delicate and high-precision tasks in the electrical sector as well as for hobbyists and model builders. The ergonomic handle design with soft zone makes it comfortable to use. The smooth-running twist cap allows users to turn the screwdriver quickly and carefully. The printed screwdriver symbols on the rotating cap make it easier to select the right screwdriver profile. Protective insulation has been integrated into the blade with the Wiha slimTECHNOLOGY specially developed for electric applications, thus ensuring blades which are up to 33% slimmer. This means low-lying screw and spring elements can easily be reached. The insulated fine screwdriver and the slimBits have undergone individual routine testing as per international IEC 60900 standard, allowing users to work safely on live parts up to 1,000 V AC. The 75 mm slimBits are compatible with all products of the Wiha ElectricVario Family.

Manufactured acc. to IEC 60900.

Content:

- 1x slimBit electric bit Slotted 2.0 mm x 75 mm (43115)
- 1x slimBit electric bit Phillips PH0 x 75 mm (43116)
- 1x slimBit electric bit Pozidriv PZ0 x 75 mm (43117)

Customs tariff number	84661038
-----------------------	----------

Self service - packing	Yes
------------------------	-----

Tool for electrics	Yes
--------------------	-----

Country of origin (ISO 3166-1 Alpha 3)	DEU
---	-----
